



Avoiding Image Retention

QUESTION: How can I avoid Image Retention on my Monitor?

ANSWER: Image retention is a slow (e.g. 10 seconds) fade out of an image that was displayed on the screen for an extended period of time. This phenomenon is referred to as image sticking in EIZO DT documentation. Although stuck images usually fade out, in extreme cases, static images displayed over a long period of time may be permanently "burned in" to the screen. This is one reason why EIZO Display Technologies recommends the use of a screen saver, to ensure images that are not being viewed are replaced by dynamic changes.